# **PIC16C84**

## **EEPROM Memory Programming Specification**

This document includes the programming specifications for the following devices:

PIC16C84

## 1.0 PROGRAMMING THE PIC16C84

The PIC16C84 is programmed using the serial method. The serial mode will allow the PIC16C84 to be programmed while in the users system. This allows for increased design flexibility.


## 1.1 <u>Hardware Requirements</u>

The PIC16C84 requires one programmable power supply for VDD (4.5V to 5.5V) and a VPP of 12V to 14V. Both supplies should have a minimum resolution of 0.25V.

## 1.2 **Programming Mode**

The programming mode for the PIC16C84 allows programming of user program memory, data memory, special locations used for ID, and the configuration word.

## Pin Diagram



## PIN DESCRIPTIONS (DURING PROGRAMMING): PIC16C84

	During Programming									
Pin Name	Pin Name	Pin Description								
RB6	CLOCK	I	Clock input							
RB7	DATA	I/O	Data input/output							
MCLR	VTEST MODE	P*	Program Mode Select							
VDD	VDD	Р	Power Supply							
Vss	Vss	Р	Ground							

Legend: I =Input, O = Output, P = Power

\*In PIC16C84, programming high voltage is internally generated. To activate the programming mode, high voltage needs to be applied to MCLR input. This means that MCLR does not draw any significant current.

## 2.0 PROGRAM MODE ENTRY

## 2.1 <u>User Program Memory Map</u>

The user memory space extends from 0x0000 to 0x1FFF (8K), of which 1K (0x0000 - 0x03FF) is physically implemented. In actual implementation the on-chip user program memory is accessed by the lower 10-bits of the PC, with the upper 3-bits of the PC ignored. Therefore if the PC is greater than 0x3FF, it will wrap around and address a location within the physically implemented memory. (See Figure 2-1).

In programming mode the program memory space extends from 0x0000 to 0x3FFF, with the first half (0x0000-0x1FFF) being user program memory and the second half (0x2000-0x3FFF) being configuration memory. The PC will increment from 0x0000 to 0x1FFF to 0x2000 to 0x3FFF and wrap around to 0x2000 (not to 0x0000). Once in configuration memory, the highest bit of the PC stays a '1', thus always pointing to the configuration memory. The only way to point to user program memory is to reset the part and reenter program/verify mode as described in Section 2.3.

In the configuration memory space, 0x2000-0x200F are physically implemented. Locations beyond 0x200F will physically access user memory. (See Figure 2-1).

## 2.2 ID Locations

A user may store identification information (ID) in four ID locations. The ID locations are mapped in [0x2000 : 0x2003]. It is recommended that the user use only the four least significant bits of each ID location. In some devices, the ID locations read-out in a scrambled fashion after code protection is enabled. For these devices, it is recommended that ID location is written as "11 1111 1000 bbbb" where 'bbbb' is ID information.

In other devices, the ID locations read out normally, even after code protection. To understand how the devices behave, refer to Table 4.3.

To understand the scrambling mechanism after code protection, refer to Section 4.0.

FIGURE 2-1: **PROGRAM MEMORY MAPPING** 0 Implemented 3FF 400 Non-implemented 1FFF 2000 Implemented 200F 2010 **ID** Location 2000 ID Location 2001 **ID** Location 2002 **ID** Location 2003 Non-implemented Reserved 2004 Reserved 2005 Reserved 2006 Configuration Word 2007 3FFF

## 2.3 **Program/Verify Mode**

The program/verify mode is entered by holding pins RB6 and RB7 low while raising MCLR pin from VIL to VIHH (high voltage). Once in this mode the user program memory and the configuration memory can be accessed and programmed in serial fashion. The mode of operation is serial, and the memory that is accessed is the user program memory. RB6 and RB7 are Schmitt Trigger Inputs in this mode.

The sequence that enters the device into the programming/verify mode places all other logic into the reset state (the  $\overline{MCLR}$  pin was initially at VIL). This means that all I/O are in the reset state (High impedance inputs).

### 2.3.1 SERIAL PROGRAM/VERIFY OPERATION

The RB6 pin is used as a clock input pin, and the RB7 pin is used for entering command bits and data input/output during serial operation. To input a command, the clock pin (RB6) is cycled six times. Each command bit is latched on the falling edge of the clock with the least significant bit (lsb) of the command being input first. The data on pin RB7 is required to have a minimum setup and hold time (see AC/DC specifications) with respect to the falling edge of the clock. Commands that have data associated with them (read and load) are specified to have a minimum delay of 1  $\mu s$  between the command and the data. After this delay, the clock pin is cycled 16 times with the first cycle being a start bit and the last cycle being a stop bit. Data is also input and output lsb first.

Therefore, during a read operation the lsb will be transmitted onto pin RB7 on the rising edge of the second cycle, and during a load operation the lsb will be latched on the falling edge of the second cycle. A minimum 1 $\mu$ s delay is also specified between consecutive commands.

All commands are transmitted lsb first. Data words are also transmitted lsb first. The data is transmitted on the rising edge and latched on the falling edge of the clock. To allow for decoding of commands and reversal of data pin configuration, a time separation of at least 1  $\mu s$  is required between a command and a data word (or another command).


The commands that are available are:

### 2.3.1.1 LOAD CONFIGURATION

After receiving this command, the program counter (PC) will be set to 0x2000. By then applying 16 cycles to the clock pin, the chip will load 14-bits in a "data word", as described above, to be programmed into the configuration memory. A description of the memory mapping schemes of the program memory for normal operation and configuration mode operation is shown in Figure 2-1. After the configuration memory is entered, the only way to get back to the user program memory is to exit the program/verify test mode by taking MCLR low (VIL).

TABLE 2-1: COMMAND MAPPING (SERIAL OPERATION)

Command		Ма	Data				
Load Configuration	0	0	0	0	0	0	0, data (14), 0
Load Data for Program Memory	0	0	0	0	1	0	0, data (14), 0
Read Data from Program Memory	0	0	0	1	0	0	0, data (14), 0
Increment Address	0	0	0	1	1	0	
Begin Programming	0	0	1	0	0	0	
Load Data for Data Memory	0	0	0	0	1	1	0, data (14), 0
Read Data from Data Memory		0	0	1	0	1	0, data (14), 0
Bulk Erase Program Memory		0	1	0	0	1	
Bulk Erase Data Memory		0	1	0	1	1	



PROGRAM FLOW CHART - PIC16C84 PROGRAM MEMORY FIGURE 2-2:




FIGURE 2-3: PROGRAM FLOW CHART - PIC16C84 CONFIGURATION MEMORY

#### 2.3.1.2 LOAD DATA FOR PROGRAM MEMORY

After receiving this command, the chip will load in a 14-bit "data word" when 16 cycles are applied, as described previously. A timing diagram for the load data command is shown in Figure 5-1.

## 2.3.1.3 LOAD DATA FOR DATA MEMORY

After receiving this command, the chip will load in a 14-bit "data word" when 16 cycles are applied. However, the data memory is only 8-bits wide, and thus only the first 8-bits of data after the start bit will be programmed into the data memory. It is still necessary to cycle the clock the full 16 cycles in order to allow the internal circuitry to reset properly. The data memory contains 64 words. Only the lower 8-bits of the PC are decoded by the data memory, and therefore if the PC is greater than 0x3F, it will wrap around and address a location within the physically implemented memory.

## 2.3.1.4 READ DATA FROM PROGRAM MEMORY

After receiving this command, the chip will transmit data bits out of the program memory (user or configuration) currently accessed starting with the second rising edge of the clock input. The RB7 pin will go into output mode on the second rising clock edge, and it will revert back to input mode (hi-impedance) after the 16th rising edge. A timing diagram of this command is shown in Figure 5-2.

## 2.3.1.5 READ DATA FROM DATA MEMORY

After receiving this command, the chip will transmit data bits out of the data memory starting with the second rising edge of the clock input. The RB7 pin will go into output mode on the second rising edge, and it will revert back to input mode (hi-impedance) after the 16th rising edge. As previously stated, the data memory is 8-bits wide, and therefore, only the first 8-bits that are output are actual data.

## 2.3.1.6 INCREMENT ADDRESS

The PC is incremented when this command is received. A timing diagram of this command is shown in Figure 5-3.

#### 2.3.1.7 BEGIN PROGRAMMING

A load command must be given before every begin programming command. Programming of the appropriate memory (test program memory, user program memory or data memory) will begin after this command is received and decoded. An internal timing mechanism executes an erase before write. The user must allow 10ms for programming to complete. No "end programming" command is required.

### 2.3.1.8 BULK ERASE PROGRAM MEMORY

To perform a bulk erase of the program memory, the following sequence must be performed.

- 1. Do a "Load Data All 1's" command.
- 2. Do a "Bulk Erase User Memory" command.
- 3. Do a "Begin Programming" command.
- 4. Wait 10 ms to complete bulk erase.

If the address is pointing to the test program memory (0x2000 - 0x200F), then both the user memory and the test memory will be erased. The configuration word will not be erased, even if the address is pointing to location 0x2007.

If the address is pointing to the test program memory (0x2000 - 0x200F), then both the user memory and the test memory will be erased. The configuration word will not be erased, even if the address is pointing to location 0x2007.

### 2.3.1.9 BULK ERASE DATA MEMORY

To perform a bulk erase of the data memory, the following sequence must be performed.

- 1. Do a "Load Data All 1's" command.
- 2. Do a "Bulk Erase Data Memory" command.
- 3. Do a "Begin Programming" command.
- 4. Wait 10 ms to complete bulk erase.

## 2.4 <u>Programming Algorithm Requires</u> Variable VDD

The PIC16C84 uses an intelligent algorithm. The algorithm calls for program verification at VDD (min.) as well as VDD (max.). Verification at VDD (min.) guarantees good "erase margin". Verification at VDD (max) guarantees good "program margin".

The actual programming must be done with VDD in the VDDP range (4.5 - 5.5V).

VDDP = Vcc range required during programming.

VDD min. = minimum operating VDD spec for the part.

VDD max.= maximum operating VDD spec for the part.

Programmers must verify the PIC16C84 at its specified VDD max. and VDD min. levels. Since Microchip may introduce future versions of the PIC16C84 with a broader VDD range, it is best that these levels are user selectable (defaults are ok).

**Note:** Any programmer not meeting these requirements may only be classified as "prototype" or "development" programmer but not a "production" quality programmer.

## 3.0 CONFIGURATION WORD

The PIC16C84 has five configuration bits. These bits can be set (reads '0') or left unchanged (reads '1') to select various device configurations.

## FIGURE 3-1: CONFIGURATION WORD BIT MAP

Bit Number:	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	_	_	_	_	_	_	_	_	_	CP	PWRTE	WDTE	FOSC1	FOSC0
bit 4:	<b>CP</b> , Code Protection Configuration Bit 1 = code protection off 0 = code protection on													
bit 3:	<b>PWRTE</b> , Power Up Timer Enable Configuration Bit  1 = Power up timer enabled  0 = Power up timer disabled													
bit 3-2:	WDTE, WDT Enable Configuration Bits 1 = WDT enabled 0 = WDT disabled													
bit 1-0	11: R0 10: H3 01: X1	<1:0>, C oscilla S oscilla C oscilla C oscilla	ator ator ator	ator Sel	ection (	Configu	ration E	Bits						

## 4.0 CODE PROTECTION

For PIC16C84 devices, once code protection is enabled, all program memory locations read out in a scrambled fashion. The ID locations and the configuration word also read out in a scrambled fashion. Further programming is disabled for the entire program memory as well as data memory. It is possible to program the ID locations and the configuration word.

## 4.1 <u>Disabling Code-Protection</u>

It is recommended that the following procedure be performed before any other programming is attempted. It is also possible to turn code protection off (code protect bit = 1) using this procedure; however, all data within the program memory and the data memory will be erased when this procedure is executed, and thus, the security of the data or code is not compromised.

Procedure to disable code protect:

- Execute load configuration (with a '1' in bit 4, code protect).
- b) Increment to configuration word location (0x2007)
- c) Execute command (000001)
- d) Execute command (000111)
- e) Execute 'Begin Programming' (001000)
- f) Wait 10ms
- g) Execute command (000001)
- h) Execute command (000111)

## 4.2 Embedding Configuration Word and ID Information in the Hex File

To allow portability of code, the programmer is required to read the configuration word and ID locations from the hex file when loading the hex file. If configuration word information was not present in the hex file then a simple warning message may be issued. Similarly, while saving a hex file, all configuration word and ID information must be included. An option to not include this information may be provided.

Specifically for the PIC16C84, the EEPROM data memory should also be embedded in the hex file (see Section 5.1). Microchip Technology Inc. feels strongly that this feature is important for the benefit of the end customer.

## TABLE 4-1: CONFIGURATION WORD

**PIC16C84** 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode			
Configuration Word (0x2007)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled			
All memory.	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled			
ID Locations [0x2000 : 0x2003]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled			

Legend: X = Don't care

## 4.3 Checksum

## 4.3.1 CHECKSUM CALCULATIONS

The checksum is calculated by summing the following:

- · The contents of all program memory locations
- The configuration word, appropriately masked
- Masked ID locations (when applicable)

The least significant 16 bits of this sum is the checksum. The following table describes how to calculate the checksum for each device. Note that the checksum calculation differs depending on the code protect setting. Since the program memory locations read out differently depending on the code protect setting, the table describes how to manipulate the actual program memory values to simulate the values that would be read from a protected device. When calculating a checksum by reading a device, the entire program memory can simply be read and summed. The configuration word and ID locations can always be read.

Note that some older devices have an additional value added in the checksum. This is to maintain compatibility with older device programmer checksums.

TABLE 4-2: CHECKSUM COMPUTATION

Device	Code Protect	Checksum*	Blank Value	0x25E6 at 0 and max address
PIC16C84	OFF	SUM[0x000:0x3FF] + CFGW & 0x1F + 0x3FE0	0x3BFF	0x07CD
	ON	SUM_XNOR7[0x000:0x3FF] + (CFGW & 0x1F   0x60)	0xFC6F	0xFC15

Legend: CFGW = Configuration Word

SUM[a:b] = [Sum of locations a to b inclusive]

SUM\_XNOR7[a:b] = XNOR of the seven high order bits of memory location with the seven low order bits summed over locations a through b inclusive. For example, location\_a = 0x123 and location\_b = 0x456, then SUM\_XNOR7 [location\_a : location\_b] = 0x001F.

\*Checksum = [Sum of all the individual expressions] **MODULO** [0xFFFF]

## 5.0 PROGRAM/VERIFY MODE ELECTRICAL CHARACTERISTICS

## 5.1 Embedding Data EEPROM Contents in Hex File

The programmer should be able to read data EEPROM information from a hex file and conversely (as an option) write data EEPROM contents to a hex file along with program memory information and fuse information.

The 64 data memory locations are logically mapped starting at address 0x2100. The format for data memory storage is one data byte per address location, lsb aligned.

TABLE 5-1: AC/DC CHARACTERISTICS
TIMING REQUIREMENTS FOR PROGRAM/VERIFY TEST MODE

## **Standard Operating Conditions**

Operating Temperature  $+10^{\circ}\text{C} \le \text{TA} \le +40^{\circ}\text{C}$ , unless otherwise stated,

(25°C is recommended)

Operating Voltage  $4.5V \le VDD \le 5.5V$ , unless otherwise stated.

Characteristic	Sym.	Min.	Тур.	Max.	Units	Conditions/Comments
Supply voltage during programming	VDDP	4.5	5.0	5.5	V	
Supply voltage during verify	VDDV	VDD min.		VDD max.	V	Note 1
High voltage on MCLR for test mode entry	VIHH	12		14.0	V	Note 2
Supply current (from VDD) during program/verify	IDDP			50	mA	
Supply current from VIHH (on MCLR)	Інн			200	μΑ	
MCLR rise time (Vss to Vhh) for test mode entry	tvhhr			1.0	μs	
(RB6, RB7) input high level	VIH1	0.8 VDD			V	Schmitt Trigger input
(RB6, RB7) input low level MCLR (test mode selection	VIL1	0.2 VDD			V	Schmitt Trigger input
RB6, RB7 setup time (before pattern setup time)	tset0	100			ns	
Data in setup time before clock ↓	tset1	100			ns	
Data in hold time after clock ↓	thld1	100			ns	
Data input not driven to next clock input (delay required between command/data or command/command)	tdly1	1.0			μs	
Delay between clock ↓ to clock ↑ of next command or data	tdly2	1.0			μs	
Clock to data out valid (during read data)	tdly3	80			ns	

Note 1: Program must be verified at the minimum and maximum VDD limits for the part.

Note 2: VIHH must be higher than VDD + 4.5V to stay in programming/verify mode.

FIGURE 5-1: LOAD DATA FOR PROGRAM MEMORY COMMAND (SERIAL PROGRAM/VERIFY)




FIGURE 5-2: READ DATA FROM PROGRAM MEMORY COMMAND (SERIAL PROGRAM/VERIFY)





FIGURE 5-3: INCREMENT ADDRESS COMMAND (SERIAL PROGRAM/VERIFY)



	IVOIVI	IAICIII	Oly i	rogi	allilli	iig 5	pecili	Cation
NOTES:								

# WORLDWIDE SALES & SERVICE

#### **AMERICAS**

#### **Corporate Office**

Microchip Technology Inc. 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 602 786-7200 Fax: 602 786-7277 Technical Support: 602 786-7627 Web: http://www.microchip.com/

#### Atlanta

Microchip Technology Inc. 500 Sugar Mill Road, Suite 200B Atlanta, GA 30350

Tel: 770 640-0034 Fax: 770 640-0307

#### **Boston**

Microchip Technology Inc. 5 Mount Royal Avenue Marlborough, MA 01752

Tel: 508 480-9990 Fax: 508 480-8575

### Chicago

Microchip Technology Inc. 333 Pierce Road, Suite 180 Itasca, IL 60143

Tel: 708 285-0071 Fax: 708 285-0075

#### **Dallas**

Microchip Technology Inc. 14651 Dallas Parkway, Suite 816 Dallas, TX 75240-8809

Tel: 214 991-7177 Fax: 214 991-8588

#### Dayton

Microchip Technology Inc. Suite 150 Two Prestige Place

Miamisburg, OH 45342 Tel: 513 291-1654 Fax: 513 291-9175

### Los Angeles

Microchip Technology Inc. 18201 Von Karman, Suite 1090

Irvine, CA 92715

Tel: 714 263-1888 Fax: 714 263-1338

#### AMERICAS (continued)

#### **New York**

Microchip Technology Inc. 150 Motor Parkway, Suite 416 Hauppauge, NY 11788

Tel: 516 273-5305 Fax: 516 273-5335

#### San Jose

Microchip Technology Inc. 2107 North First Street, Suite 590 San Jose, CA 95131

Tel: 408 436-7950 Fax: 408 436-7955

### **Toronto**

Microchip Technology Inc. 5925 Airport Road, Suite 200 Mississauga, Ontario L4V 1W1, Canada Tel: 905 405-6279 Fax: 905 405-6253

## ASIA/PACIFIC

### **Hong Kong**

Microchip Technology Rm 3801B, Tower Two Metroplaza, 223 Hing Fong Road, Kwai Fong, N.T., Hong Kong Tel: 852 2 401 1200 Fax: 852 2 401 3431

#### Korea

Microchip Technology 168-1, Youngbo Bldg. 3 Floor Samsung-Dong, Kangnam-Ku, Seoul, Korea

Tel: 82 2 554 7200

64 7200 Fax: 82 2 558 5934

#### Singapore

Microchip Technology 200 Middle Road #10-03 Prime Centre Singapore 188980

Tel: 65 334 8870 Fax: 65 334 8850

#### Taiwan

Microchip Technology 10F-1C 207 Tung Hua North Road Taipei, Taiwan, ROC

Tel: 886 2 717 7175 Fax: 886 2 545 0139

#### **EUROPE**

### **United Kingdom**

Arizona Microchip Technology Ltd. Unit 6, The Courtyard Meadow Bank, Furlong Road Bourne End, Buckinghamshire SL8 5AJ Tel: 44 1 628 850303 Fax: 44 1 628 850178

#### France

Arizona Microchip Technology SARL Zone Industrielle de la Bonde 2 Rue du Buisson aux Fraises 91300 Massy - France Tel: 33 1 69 53 63 20 Fax: 33 1 69 30 90 79

#### Germany

Arizona Microchip Technology GmbH Gustav-Heinemann-Ring 125 D-81739 Muenchen, Germany Tel: 49 89 627 144 0 Fax: 49 89 627 144 44

### Italy

Arizona Microchip Technology SRL
Centro Direzionale Colleoni
Palazzo Taurus 1 V. Le Colleoni 1
20041, Agrate Brianza, Milan Italy
Tel: 39 39 689 9939 Fax: 39 39 689 9883

#### **JAPAN**

Microchip Technology Intl. Inc. Benex S-1 6F 3-18-20, Shin Yokohama Kohoku-Ku, Yokohama Kanagawa 222 Japan

Tel: 81 45 471 6166 Fax: 81 45 471 6122

5/10/96



All rights reserved. © 1996, Microchip Technology Incorporated, USA.

Information contained in this publication regarding device applications and the like is intended through suggestion only and may be superseded by updates. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights. The Microchip logo and name are registered trademarks of Microchip Technology Inc. All rights reserved. All other trademarks mentioned herein are the property of their respective companies.