

EM 60000 Note code list :

	C Do	C# Do#	D Re	D# Re#	E Mi	F Fa	F# Fa#	G So	G# So#	A La	A# La#	B Si
2										00	01	02
3	03	04	05	06	07	08	09	0A	0B	0C	0D	0E
4	0F	10	11	12	13	14	15	2A	2B	2C	2D	2E
5	2F	30	31	32	33	34	35	4A	4B	4C	4D	4E
6	4F	50	51	52	53	54	55	56	57	58	59	5A

stop code = 7F (結束碼)

silecne code = 7E (休止符)