

PAW3602DH-NF CMOS LASER MOUSE SENSOR

General Description

PAW3602DH-NF is a CMOS laser mouse sensor with DSP integration chip that serves as a non-mechanical motion estimation engine for implementing a computer mouse.

D, VDDA)
2
moving (Normal)
not moving (Sleep) wn mode
n

Ordering Information

Order number	I/O		Resolution	
PAW3602DH-NF	CMOS o	utput	800/1600 cp	oi

1. Pin Description

Pin No.	Name	Type	Definition
1	LD_P	PWR	LD control
2	LD_N	PWR	LD control
3	OSCOUT	OUT	Resonator output
4	OSCIN	IN	Resonator input
5	VDDD	PWR	Chip digital power, 3.3V
6	VSSD	GND	Chip digital ground
7	VSSA	GND	Chip analog ground
8	VDD	PWR	Chip power, 5V power supply
9	VDDA	PWR	Chip analog power, 3.3V
10	LDRES	IN	Connect to resistor input
11	YA	I/O	LD BIST mode input / YA quadrature output
12	YB	I/O	LD BIST mode input / YB quadrature output
13	XA	I/O	LD BIST mode input / XA quadrature output
14	XB	OUT	LD BIST mode fail output XB quadrature output
15	СРІ	IN	CPI select pin Pull-high to VDD: 800 cpi (Default) Pull-down to GND: 1600 cpi
16	LDTEST	IN	LD test pin Floating (Chip internal pull-down): Disable LD test mode Pull-high (3.3V ONLY): Enable LD test mode
17	NC	-	No connection
18	SCLK	IN	Serial interface clock
19	SDIO	I/Q	Serial interface bi-direction data
20	PD	ÍN	Power down pin, active high




Figure 1. Top View Pinout Figure 2. Top View of Mouse

2. Block Diagram and Operation





Figure 3. Block Diagram

The PAW3602DH-NF is a high performance CMOS laser mouse sensor with DSP integration chip that serves as a non-mechanical motion estimation engine for implementing a computer mouse. It is based on new laser speckle navigation technology. In the laser mouse, it uses laser diode (LD), specially uses VCSEL (Vertical Cavity Surface Emitting Laser) as light source, where laser is one kind of coherent light. When this light illuminates on the working surface, the surface will reflect and diffuse the incident light and generates speckle pattern. The imaging sensor in the laser mouse chip detects the speckle pattern that generated from the working surface and determines the movement and direction. Since the speckle pattern can be generated on the most of the surface if this surface is not perfect smooth or transparent, the laser mouse can adapt on more surfaces as compared with traditional LED-based optical mouse.

The PAW3602DH-NF has an extra function, eye safety protection circuit. The embedded eye safety protection circuit will detect if LD_P pin is short to power, if LD_N pin is short to ground, or if LD_RES pin is short to ground to be a large LD power. And this will protect users from eye injured for large LD power. This mouse sensor is in a 20-pin optical package. The output format is two-channel quadrature (X and Y direction), which emulates encoder phototransistors. The current X and Y information are also available in registers accessed via a serial port. The word "mouse sensor," instead of PAW3602DH-NF, is used in the document.



3. Registers and Operation


The mouse sensor can be programmed through registers, via the serial port, and DSP configuration and motion data can be read from these registers. All registers not listed are reserved, and should never be written by firmware.

3.1 Registers

Address	Name	R/W	Default	Data Type
0x00	Product_ID	R	0x30	Eight bits [11:4] number with the product identifier
0x01	Product_ID	R		Four bits [3:0] number with the product identifier Reserved [3:0] number is reserved for further
0x02	Motion_Status	R	-	Bit field
0x03	Delta_X	R	-	Eight bits 2's complement number
0x04	Delta_Y	R	-	Eight bits 2's complement number
0x05	Operation_Mode	R/W	-	Bit field
0x06	Configuration	R/W	-	Bit field
0x07	Image_Quality	R	-	Bit field

3.2 Register Descriptions

0x00		Product_ID										
Bit	7	7 6 5 4 3 2 1 0										
Field		PID[11:4]										
Usage	The value is OK.	The value in this register can't change. It can be used to verify that the serial communications link is OK.										
0x01				Produ	ict_ID	7						
Bit	7	6	5	4	3	2	1	0				
Field		PID[3:0] Reserved [3:0]										
Usage	communica		OK. Reserve			o verify that the 0x0 and 0xF, it		sed to verify				



0x02				Motion	_Status					
Bit	7	6	5	4	3	2	1	0		
Field	Motion	Reserv	ed[3:2]	DYOVF	DXOVF	Reserv	ed[1:0]	RES		
Usage	so, then the the motion be Reading this reading the	user should in outfers have so register free Delta_X and	lows the user to determine if motion has occurred since the last time it was read. If should read registers 0x03 and 0x04 to get the accumulated motion. It also tells if rs have overflowed since the last reading. The current resolution is also shown. In the current resolution is also shown.							
Notes	Field Name	Descri	ption					5		
	Motion	0 = Nc	n since last re motion (De ption occurre	- 1-	for reading i	n Delta_X a	und Delta_Y	registers		
	Reserved[3:	[2] Reserv	ed for future	3			NV			
	DYOVF	0 = Nc	Motion Delta Y overflow, ΔY buffer has overflowed since last report 0 = No overflow (Default) 1 = Overflow has occurred							
	DXOVF	0 = Nc	n Delta X ove overflow (L rerflow has o		uffer has ove	rflowed sinc	ce last repor	rt		
	Reserved[1:	0] Reserv	ed for future			V				
	RES	Resolu 0 = 16 1 = 80		s per inch		V				
0x03			7	Delt	a_X					
Bit	7	6	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	4	3	2	1	0		
Field	X7	X6 \	X5	X4	X3	X2	X1	X0		
Usage		X movement is counts since last report. Absolute value is determined by resolution. Reading clears the register. Report range –128~+127.								
0x04		7		Delt	a_Y					
Bit	7	6	6 5 4 3 2 1 0							
Field	Y7	Y6	Y6 Y5 Y4 Y3 Y2 Y1 Y0							
Usage	Y movement is counts since last report. Absolute value is determined by resolution. Reading clears the register. Report range –128~+127.									


0x05		T		Operation	_Mode	ı.					
Bit	7	6	5	4	3	2	1	0			
Field	LDsht_enh	XY_enh	Reserved	Slp_enh	Slp2au	Slp2mu	Slp1mu	Wakeup			
Usage	Register 0x05 al default values, a	llows the user to change the operation of the sensor. Shown below are the bits, their									
	ŕ		values.		12						
	Operation_Mode "0xxxx"=Disabl		le				$\mathscr{A} / \mathscr{C}$				
	"10xxx"=Enable	sleep mod	e^1					Jan V			
	"11xxx"=Enable "1x100"=Force				($\mathcal{D}_{\mathcal{D}}$			
	"1x010"=Force	enter sleep1	3	2	/			$\stackrel{\circ}{>}$			
	"1x001"=Force	wakeup from	m sleep mode	,3	___\			\mathcal{V}			
	Notes: 1. Enable sleep r	mode but d	isable automa	itic entering	sleen? mod	e that is only	2 modes wi	U II be used			
	normal mode										
	sleep1 mode,	and keep o	n sleep1 mod	e until mov	ing is detecte	ed or wakeup	is asserted.				
	2. Enable sleep i										
	mode. After 0 sleep1 mode i					ill enter sleep	mode, and	keep on			
	And after 27.3 sleep2 mode						2 mode, and	keep on			
	3. Only one of the others have to internal signal	be set to 0									
Notes	Field Name	Descripti	on			_					
Notes		\~	r enable / disa	able		\forall					
	LDsht_enh	0 = Disab	le								
			le (Default) ature output e	enable/disab	ole						
	XY_enh	0 = Disab	le								
		2/1	le (Default)								
	Reserved	V~	for future. M		en to zero						
	Slp_enh	Sleep mod 0 = Disab	de enable/disa	able							
	Sip_cini	1 = Enab	le (Default)								
~	Slp2au		e enter sleep2 le (Default)	mode enab	le/disable						
	Sipzau (0 = Disab 1 = Enabl		<u> </u>							
1	Slp2mu	Manual er	nter sleep2 m	ode, set "1"	will enter sle	eep2 and this	bit will be re	set to "0"			
	Slp1mu					eep2 and this					
	Wakeup	Manual w		sleep mode,	set "1" will	enter wakeup	and this bit	will be			

0x06				Confi	guration						
Bit	7	6	5	4	3	2	1	0			
Field	Reset		Reserved[3:2] PD Reserved[1:0] RES								
Usage			ion register allows the user to change the configuration of the sensor. are the bits, their default values, and optional values.								
Notes	Field Name	e Des	Description								
		Res	set full chip			My V		July 1			
	Reset	0 =	Normal ope	eration (Defa	ult)						
		1 =	Reset the ful	lly chip							
	Reserved[3	:2] Res	served for fut	ure. Must be	written to "0	0,2		2/			
		Pov	ver down mo	de) / ($\overline{\gamma}$			
	PD		-	eration (Defa	ult)			,			
		1 =	Power down	mode							
	Reserved[1	:0] Res	served for fut	ure. Must be	written to "0	0"					
	RES	on reg				initial state, to the register					
0x07		((Image	_Quality						
Bit	7	6	5	4	3	2	1	0			
Field				Img	qa[7:0]						
Usage			ality level of ormally work		the current	frame. Report	range 0~255	5. The			
Notes	Field Name	e Des	cription								
	Imgqa[7:0]	Ima	ge quality rep	oort range: 0(worst) ~ 255	(best).					

4. LD BIST (Built in Self Test) Mode

The mouse sensor can be performed the LD driver error detection function by manufactures to fit the LD power in eye safety rule. LD BIST mode is enabled by pull-high (3.3V ONLY) the LDTEST pin. Once LDTEST pin is pulled high, the XA, YB, YA pin are changed to be input pin and become the LD test mode input [XA,YB,YA], XA is MSB and YA is LSB. At this moment, XB is also changed to LD test fail output.

Pin Name	Description
LDTEST	LD Test Mode disable/enable 0 = Disable (Default) 1 = Enable
[XA, YB, YA]	"000" = Mode 0, Measure LD power, BIST if eye safety error detection function is fail in normal mode "001" = Mode 1, BIST if LD_P error detection function is fail "010" = Mode 2, BIST if LD_N error detection function is fail "011" = Mode 3, BIST if LDRES pin is short to GND
XB	0 = PASS 1 = FAIL



5. Specifications

5.1 Absolute Maximum Ratings

Stresses above those listed under "Absolute Maximum Rating" may cause permanent damage to the device. These are stress ratings only. Functional operation of this device at these or any other conditions above those indicated in the operational sections of this specification is not implied and exposure to absolute maximum rating conditions for extended periods may affect device reliability.

Symbol	Parameter	Min	Max	Unit	Notes
T_{STG}	Storage Temperature	-40	85	°C	
TA	Operating Temperature	-15	55	°C	
V	DC Country Walter	-0.5	$V_{dd1}+0.3$	V	
V_{DC}	DC Supply Voltage	-0.5	$V_{dd2}+0.5$	V	
$V_{\rm IN}$	DC Input Voltage	-0.5	V _{DC}	V	All I/O pin except LDTEST pin (LDTEST high is 3.3V only)
	Lead Solder Temp		260	°C	For 10 seconds, 1.6mm below seating plane.
ESD			2	kV	All pins, human body model MIL 883 Method 3015


5.2 Recommend Operating Condition

Symbol	Parameter	Min.	Тур.	Max.	Unit	Notes
T_{A}	Operating Temperature	0		40	°C	
V_{dd1}	Power Supply Voltage	3.0	3.3	3.6		VDDD, VDDA short
V_{dd2}	Tower Supply Voltage	4.25	5	5.5		VDD
V_N	Supply Noise		/	80	mV	Peak to peak within 0 - 80 MHz
Z	Distance from Lens Reference Plane to Surface	2.3	2.4	2.5	mm	
R	Resolution		800	1600	CPI	
SCLK	Serial Port Clock Frequency			<u> </u>	MHz	
F_{CLK}	Clock Frequency		27)	MHz	
FR	Frame Rate	//	6600	/	frames/s	
S	Speed		28		inches/s	

5.3 AC Operating Condition

Electrical Characteristics over recommended operating conditions. Typical values at 25 °C, $V_{dd1} = 3.3 \text{ V}$, $F_{CLK} = 27 \text{ MHz}$.


Symbol	Parameter	Min.	Тур.	Max.	Unit	Notes
t_{PDR}	PD Pulse Register			152	us	One frame time maximum after setting PD_enh bit in the Configuration register @6600frame/sec (refer to Figure 14).
t_{PD}	Power Down		500		us	From PD↑ (refer to Figure 10)
$t_{ m PDW}$	PD Pulse Width	700			us	Pulse width to reset the serial interface (refer to Figure 10).
$t_{ m PUPD}$	Power Up from PD↓	8		14.5	ms	From PD↓ to valid quad signals. After t _{PUPD} , all registers contain valid data from first image after PD↓. Note that an additional 90 frames for Auto-Exposure (AE) stabilization may be required if mouse movement occurred while PD was high (refer to Figure 10).
$t_{ m PU}$	Power Up from V _{DD} ↑	8		14.5	ms	From V _{DD} ↑ to valid quad signals. 500usec + 90 frames.
$t_{ m HOLD}$	SDIO Read Hold Time		3	2	us	Minimum hold time for valid data (refer to Figure 9).
t_{RESYNC}	Serial Interface RESYNC.	1	,	5	us	@6600 frame/sec (refer to Figure 11)
t_{SIWTT}	Serial Interface Watchdog Timer Timeout	1.7			ms	@6600 frame/sec (refer to Figure 11)
t_r, t_f	Rise and Fall Times: SDIO		35, 25		ns	$C_L = 30 \mathrm{pF}$
t_r, t_f	Rise and Fall Times: XA, XB, YA, YB	7	30, 25		ns	$C_D = 30 \text{ pF}$
t_r, t_f	Rise and Fall Times: I _{LD}		80, 30		ns	LD bin grade: P64; R1 = 13.2 Kohm



5.4 DC Operating Condition


Electrical Characteristics over recommended operating conditions. Typical values at 25 °C, $V_{dd1} = 3.3 \text{ V}$, $F_{CLK} = 27 \text{ MHz}$.

Symbol	Parameter	Min.	Typ.	Max.	Unit	Notes	
Type: PWR							
I_{DD}	Supply Current Mouse moving (Normal)		17		mA	Sensor + LD	
I_{DD}	Supply Current Mouse not moving (sleep1)		5		mA	Sensor + LD	
I_{DDPD}	Supply Current (Power Down)		200		uA	PD, SCLK, SDIO = high Sensor + LD	
Type: S	Type: SCLK, SDIO, PD						
V _{IH}	Input voltage HIGH	2.0	C				
$V_{\rm IL}$	Input voltage LOW		2	0.7	V		
V _{OH}	Output voltage HIGH	2.4		\ \ \	V	@I OH = 2mA (SDIO only)	
V _{OL}	Output voltage LOW			0.6	V	@I OL = 2mA (SDIO only)	
Type: L	DTEST		(
V _{IH}	Input voltage HIGH	2.0		M	A		
$V_{\rm IL}$	Input voltage LOW	,		0.7	V		
Type: XA, XB, YA, YB							
V_{OH}	Output voltage HIGH	2.4			V	@I _{OH} ≠ 2mA	
V _{OL}	Output voltage LOW			0.6	V	$@I_{OL} = 2mA$	



6. Quadrature Mode

The quadrature state of the mouse sensor tells mouse controller which direction the mouse is moving in. The output format is two channels quadrature (X and Y direction), which emulates encoder phototransistors. The DSP generates the Δx and Δy relative displacement values that are converted into two channel quadrature signals. The following diagrams show the timing for positive X motion, to the right or positive Y motion, up.



6.2 Quadrature Output State Machine

The following state machine shows the states of the quadrature output pins. The three things to note are that state 0 is entered after a power on reset. While the PD pin is asserted, the state machine is halted. Once PD is deasserted, the state machine picks up from where it left off. During times of mouse no movement will entry power saving mode, until mouse was moved.




Figure 5. State machine

6.3 Quadrature Output Waveform

The following diagrams show the waveform of the two channel quadrature outputs. If the X, Y is motionless, the (XA, XB), (YA, YB) will keep in final state. Each state change (ex. STATE2 \rightarrow STATE3) is one count.




Figure 6. Quadrature output waveform

7. Serial Interface

The synchronous serial port is used to set and read parameters in the mouse sensor, and can be used to read out the motion information instead of the quadrature data pins.

SCLK: The serial clock line. It is always generated by the host micro-controller.

SDIO: The serial data line used for write and read data.

PD: A third line is sometimes involved. PD (Power Down pin) is usually used to place the mouse sensor in a low power mode to meet USB suspend specification. PD can also be used to force re-synchronization between the micro-controller and the mouse sensor in case of an error.

7.1 Transmission Protocol

The transmission protocol is a two-wire link, half duplex protocol between the micro-controller and mouse sensor. All data changes on SDIO are initiated by the falling edge on SCLK. The host micro-controller always initiates communication; the mouse sensor never initiates data transfers.

The transmission protocol consists of the two operation modes:

- Write Operation.
- Read Operation.

Both of the two operation modes consist of two bytes. The first byte contains the address (seven bits) and has a bit7 as its MSB to indicate data direction. The second byte contains the data.





Figure 7. Transmission protocol

7.1.1 Write Operation


A write operation, which means that data is going from the micro-controller to the mouse sensor, is always initiated by the micro-controller and consists of two bytes. The first byte contains the address (seven bits) and has a "1" as its MSB to indicate data direction. The second byte contains the data. The transfer is synchronized by SCLK. The micro-controller changes SDIO on falling edges of SCLK. The mouse sensor reads SDIO on rising edges of SCLK.



14

7.1.2 Read Operation

A read operation, which means that data is going from the mouse sensor to the mouse controller, is always initiated by the mouse controller and consists of two bytes. The first byte contains the address, is written by the mouse controller, and has a "0" as its MSB to indicate data direction. The second byte contains the data and is driven by the mouse sensor. The transfer is synchronized by SCLK. SDIO is changed on falling edges of SCLK and read on every rising edge of SCLK. The mouse controller must go to a high Z state after the last address data bit. The mouse sensor will go to the high Z state after the last data bit.



7.2 Re-Synchronous Serial Interface

If the mouse controller and the mouse sensor get out of synchronization, then the data either written or read from the registers will be incorrect. There are two different ways for re-synchronous serial interface.

- Re-synchronous serial interface using PD pin (see Section 7.2.1)
- Re-synchronous serial interface using watchdog timer timeout (see Section 7.2.2)

Note that "watchdog timer timeout" (see Section 7.2.2) function is disabled when the mouse sensor is in the power down mode. If the user uses this function during the power down mode, it will get out of synchronization. The mouse sensor and the mouse controller also might get out of synchronization due to following conditions.

- Power On Problem. The problem occurs if the mouse sensor powers up before the mouse controller sets the SCLK and SDIO lines to be output. The mouse sensor and the mouse controller might get out of synchronization due to power on problem. An easy way to solve this is to raise PD pin (see Section 7.2.1) or use watchdog timer timeout (see Section 7.2.2) for re-synchronous serial interface.
- ESD Events The mouse sensor and the mouse controller might get out of synchronization due to ESD events. An easy way to solve this is to raise PD pin (see Section 7.2.1) or use watchdog timer timeout (see Section 7.2.2) for re-synchronous serial interface.
- USB suspend Termination of a transmission by the mouse controller may be required sometimes (for example, due to a USB suspend interrupt during a read operation). An easy way to solve this is to raise PD pin (see Section 7.2.1) or use watchdog timer timeout (see Section 7.2.2) for re-synchronous serial interface.

15

7.2.1 Re-Synchronous Serial Interface Using PD Pin

The mouse controller raises PD line to reach re-synchronous serial interface after an incorrect read. The mouse sensor will reset the serial port but will not reset the registers and be prepared for the beginning of a new transmission. Note that using "PD pin" to reach re-synchronous is quicker than using "watchdog timer timeout".




Figure 10. Re-synchronous Serial Interface Using PD Pin

7.2.2 Re-Synchronous Serial Interface Using Watchdog Timer Timeout

The mouse controller can toggle the SCLK line from high to low to high and wait at least t_{SIWTT} to reach resynchronous serial interface after an incorrect read. The mouse sensor will reset the serial port but will not reset the registers and be prepared for the beginning of a new transmission.





Figure 11. Re-synchronous Serial Interface Using Watchdog Timer Timeout

7.3 Collision Detection on SDIO

The only time that the mouse sensor drives the SDIO line is during a READ operation. To avoid data collisions, the micro-controller should release SDIO before the falling edge of SCLK after the last address bit. The mouse sensor begins to drive SDIO after the next falling edge of SCLK. The mouse sensor release SDIO of the rising SCLK edge after the last data bit. The micro-controller can begin driving SDIO any time after that. In order to maintain low power consumption in normal operation or when the PD pin is pulled high, the micro-controller should not leave SDIO floating until the next transmission (although that will not cause any communication difficulties).



7.4 Power Down Mode

There are two different ways to entry power down mode, using the PD line or register setting.

7.4.1 PD Line Power Down Mode

To place the mouse sensor in a low power mode to meet USB suspend specification, raise the PD line at least 700us. Then PD line can stay high, with the mouse sensor in the shutdown state, or the PD pin can be lowered, returning the mouse sensor to normal operation.




Figure 12. Power down minimum pulse width




Figure 13. PD line power down mode

7.4.2 Register Power Down Mode

The mouse sensor can be placed in a power down mode by setting **PD_enh** bit in the **configuration** register via a serial port write operation. After setting the **configuration** register, wait at least 1 frame times. To get the chip out of the power down mode, clear **PD_enh** bit in the **configuration** register via a serial port write operation. In the power down mode, the serial interface watchdog timer is not available (see Section 7.2.2). But, the serial interface still can read/write normally. For an accurate report after leave the power down mode, wait about 3 ms before the mouse controller is able to issue any write/read operation to the mouse sensor.



Figure 14. Power-down Configuration Register Writing Operation

17

All rights strictly reserved any portion in this paper shall not be reproduced, copied or transformed to any other forms without permission.

7.4.3 Register Power Down Mode

The mouse sensor can be placed in a power-down mode by setting bit 3 in the configuration register via a serial port write operation. After setting the configuration register, wait at least 1 frame times. To get the chip out of the power-down mode, clear bit 3 in the configuration register via a serial port write operation. In power-down mode, the serial interface watchdog timer is not available. But, The serial interface still can read/write normally. For an accurate report after leave power down mode, wait about 3ms before the micro-controller is able to issue any write/read operation to the mouse sensor.





Figure 15. Power-down configuration register writing operation

7.5 Error Detection

- 1. The micro-controller can verify success of write operations by issuing a read command to the same address and comparing written data to read data.
- 2. The micro-controller can verify the synchronization of the serial port by periodically reading the product ID register.



8. Referencing Application Circuit

8.1 Typical Application using Serial Interface for Full Speed USB Wire Mouse




Figure 16. Application Circuit Using Serial Interface with MosArt MA6721 (Full Speed USB)

8.2 Typical Application using Serial Interface for Low Speed USB Wire Mouse




Figure 17. Application circuit using serial interface with Cypress CY7C63813 (Low Speed USB)

8.3 Typical Application for Wireless Laser Mouse, Power Source from Pin 5 & 9




Figure 18. RF application circuit using pin 5 & 9 for power supply source

8.4 Typical Application for RF Receiver





Figure 19. Application circuit with Cypress CY7C63813 (Low speed USB)

9. PCB Layout Consideration



11. Package Information




Figure 21. Package outline drawing

11.2 Base Plate Modeling Dimension





Figure 22. Base plate molding dimension



11.3 Recommended PCB Mechanical Cutouts and Spacing





Figure 23. Recommended PCB mechanical cutouts and spacing



6. Update History

Version	Update	Date
V1.0	Creation, Preliminary 1 st version	06/28/2007



Vertical Cavity Surface Emitting Laser

(VCSEL)

Components Specification

Distribution

Internal Only

External All

Document No.: PNDR-00004

Revision: Rev 2.50

Date: 2007/06/15

Revision History

_	_	_	
Revision	Author	Date	Description
1.0	M.H.Chien	2006/06/14	Initial version
1.5	Chadwick	2007/01/18	Add VDD=2.7V and delete VDD=5.0V constraint resistor table
2.0	Chadwick	2007/05/04	Revise resistor table for higher CW radiant power 300uW ~550uW on Mouse operation; Delete P32/ P64/ P68/ P72/ P76/ P80 six Grades
2.5	Chadwick	2007/06/15	Note PAN/PAW 3601DH-NF for constraint resistor table and add new constraint resistor table for PAN/PAW 3602DH-NF



PNDR-00004

850nm Epoxy molded VCSEL for Laser Mouse

FEATURES

- Epoxy Molded with round emission surface.
- Small divergence angle.



ELECTRO-OPTICAL CHARACTERISTICS:

PARAMETERS	SYMBOL	MIN TYP	MAX	UNIT	TEST CONDITIONS
Output Power	Po	0.475	0.7	mW	= _F (1)
Wavelength	λ_{P}	830 850	860	nm	I _E = 6 mA
Forward Voltage	V_{F}	1.6 1.75	1.9	X	I _F = 6 mA
Series Resistance	R_{s}	40	60	Ω	I _F = 6 mA
Breakdown voltage	V_{BD}	7 14		V	Ir = 10uA
Beam Divergence(1/e ²)	θ	8		degree	I _F = 6 mA

Notes:(1) Binning

APPIY TO PAN3602DH-NF/ PAW3602DH-NF

Optical power at each of following nominal bin operating current and constrained resistor

1, 1							
Bin grade	LD current (mA)	Single Constrain resistor : $R(\Omega)$	Bin grade	LD current (mA)	Single Constrain resistor :R(Ω)		
P36	3.6	18K	P50	5.0	13K		
P40	4.0	15K	P52	5.2	13K		
P42	4.2	15K	P54	5.4	12K		
P44	4.4	15K	P56	5.6	12K		
P46	4.6	15K	P58	5.8	12K		
P48	4.8	13K	P60	6.0	10K		

Warning! For Single constrain resistor(R), please using the recommend value, if resistor value is less than recommend value, there will be eye safety issue.


Note: The suggested resistor tolerance is 1% precise resistor for constrained resistor R.


ABSOLUTE MAXIMUM RATINGS:

PARAMETERS	MIN	MAX	UNIT	Condition
Storage Temperature	-30	85	°C	
Operating Temperature	-10	60	°C	
Continuous Forward Current		12	mA	
Continuous Reverse Voltage		7	V	
Lead Solder Temperature		260	℃C	10 seconds


Fig. 1 Typical Optical Characteristics

Fig. 2 Typical Electrical Characteristics





OUTLINE DIMENSIONS:




Note: Unit is millimeters and Tolerance is ± 0.2 mm unless otherwise notes

WARNING:

The VCSEL is a class IIIa laser in the safety standard ANSI Z136.1 and should be treated as a potential eye hazard.



PNLR-00038 Lens Dimensions



Note: The Part No. of the Mouse Product with Prefix "PAN" shall NOT be made, sold, offered to sell, imported or used in or into USA, Canada, Japan and EU. For "PAN", PixArt has only gained territory-limited patent license from Avago. Avago reserve right to take legal action against our customers who fails to comply the above term. PLEASE NOTE THAT PixArt will NOT defend, indemnify, or provide any assistance to our customers who fail to comply the term. IF YOU DO NOT AGREE THE TERM, PIXART WILL NOT DELIVER "PAN" PRODUCTS TO YOU.

