


TRINAMIC Motion Control GmbH & Co. KG Sternstrasse 67 D – 20357 Hamburg GERMANY

WWW.TRINAMIC.COM

TMC 423 – Datasheet Serial Triple Incremental Encoder Interface



TMC₄₂₃ Main Features

The TMC423 is a triple incremental encoder input chip, which interfaces to any SPI[™] compatible controller. The TMC423 can especially be used in conjunction with the TMC428 triple stepper motor controller to provide position verification or stabilization using some additional software. It integrates 24 bit counters for each encoder to provide a high position resolution without CPU interaction. Further it allows dynamic resolution adaptation to allow direct comparison of encoder counters with motors using different micro step resolution. All encoder counters can be latched synchronously, or whenever a null channel event occurs, providing a position on strobe holding function. The TMC428 as an optional function. A multiplexer function is also integrated for the TMC428 reference switches. Furthermore control and drive of a LED and switch matrix is implemented. All functions can also be used in conjunction.

Applications

- Stepper Motor Position Verification
- Position Maintenance
- Incremental Encoder Interface Readout
- Step / Direction conversion for TMC428 systems
- Control of LED 6 x 4 Matrix and Switch 6 x 4 Matrix

Features

- Supports 2 and 3 channel incremental encoders with a wide range of resolutions
- Allows step / direction signal extraction from TMC428 output data stream
- Programmable pulse shaping for step / direction interface
- 24 bit integrated position resolution
- Programmable prescaler for Incremental Encoder Interface
- 4-times evaluation of encoder signals
- Fast 32 bit SPI[™] interface
- Can share SPI[™] interface with TMC428 and supplies separate interrupt output
- Integrates Reference Switch Multiplexers
- Package: TQ100

Note: SPI is Trademark of Motorola, Inc.

Revision History

Version	Comment	Date	Name
Initial Version		November 22, 2002	Technical Department
0.4	Corrected Array Switching Frequency	January 23, 2003	Technical Department
0.5	First Customer Release	January 24, 2003	Technical Department
0.6	Minor corrections	March 11, 2003	Technical Department
0.6	Changes concerning new company TRINAMIC Motion Control GmbH & Co. KG	October 1 st , 2004	Technical Department
0.7	Corrected Pinning: Position of CLK pin	December, 15 th , 2004	Technical Department
1.0	Corrected Reset input in diagram, added supply spec	March, 15 th , 2005	Technical Department
1.1	Added Application Environment examples	March, 9 th , 2007	Technical Department
1.1	Added encoder timing	Apr, 4 th , 2007	Dw
1.2	S/D Appl. corrected, added TMC428 SPI datagram for S/D	June 6 th , 2007	НС
1.3	Figure 4 and Figure 5: TMC423 clock input corrected; more detailed flag description	June 20 th , 2007	HC, Dw

Table of Contents

1	Pinc	put	
	1.1	Pin Description	6
	1.2	Recommended Operating Conditions	
	1.3	Electrical Characteristics	7
2	Bloc	k Diagram	8
3	Арр	lication Environment	9
	3.1	Application Description	
	3.1.1	- · · F L · · · · · · · · · · · · · · · ·	
	3.1.2		9
	3.2	Application Examples	10
	3.2.1	Application with TMC236 Stepper Motor Driver	10
	3.2.2		
4	Dyn	amic Resolution Adaptation	11
5	Seri	al Peripheral Interface (SPI) with 32-bit Register	12
	5.1	Description and Specification	12
	5.2	32-bit SPI Datagram Structure	13
	5.3	SPI 32-bit Datagram Specification	
	5.3.1		
6	Incr	emental Encoder	14
7	Con	figuration Datagrams	
	7.1	Encoder Interface Prescaler and Null Event Configuration	15
	7.2	Encoder Interface Hold Register Operation	
	7.3	Timer Logic Step Pulse Length and Delay	
	7.4	Control Register and Interrupt Control	
	7.5	Switch Matrix Read	
	7.6	LED Matrix Write	
8	SPI-	Protocol for Interface with 6-bit Register	
	8.1	Step and Direction Pulse conversion	
9	LED	and Switch Matrix	19
1(o Pack	age dimensions	20

List of Figures

Figure 1: Pinout TMC4235 Figure 2: Block diagram of the TMC423 8 Figure 3: Application Environment Figure 4: Example for Application with TMC236 Stepper Motor Driver 10 Figure 5: Example for Application with Step / Direction Power Stage 10 Figure 6: TMC423 Application 11 Figure 7: Timing diagram of the Serial Interface 12 Figure 8: Structure 32-Bit Interface 13 Figure 9: Overview TMC423 Registers 13 Figure 10: Encoder Output and Evaluation 14 Figure 11: Crosstalk on Encoder Wire 14 Figure 12: Step Direction conversion 18 Figure 13: Connection to the matrix 19 Figure 14: 100-Pin TQFP Top View 20 Figure 15: 100-Pin TQFP Side View 20 Figure 16: 100-Pin TQFP Side View Detail A 20

List of Tables

Table 1: TMC423 Pinout 7 Table 2: Operating Conditions 7 Table 3: Operating Conditions 7 Table 4: Prescaler factors for different motors and encoders 11 Table 5: Interrupt Flags 13
 Table 6: SPI Datagram Prescaler 16
 Table 7: SPI Datagram Hold Register 16 Table 8: SPI Datagram Step-/Dir logic 17 Table 9: SPI Datagram Control Register 17 Table 10: Switch Matrix Read 17 Table 11: LED Matrix Write 17 Table 12: SPI Datagram Step / Direction Converter 18 Table 13: Datagram example and RAM contents for three step-direction drivers 18 Table 14: TMC423 LED Matrix Pins 19 Table 15: TQFP Dimensions 21

1 Pinout




Figure 1: Pinout TMC423

1.1 Pin Description

Pin	Location	Dir	Description
GND	1, 9, 36, 39, 51, 68, 69, 91	In	Ground
ENC1 A	3	In	Incremental Encoder Interface 1 Channel A
ENC1 B	4	In	Incremental Encoder Interface 1 Channel B
ENC1_N	5	In	Incremental Encoder Interface 1 Channel N
	-		(Connect to +5V if not used)
ENC2_A	6	In	Incremental Encoder Interface 2 Channel A
ENC2 B	10	In	Incremental Encoder Interface 2 Channel B
ENC2_N	11	In	Incremental Encoder Interface 2 Channel N
-			(Connect to +5V if not used)
ENC3_A	12	In	Incremental Encoder Interface 3 Channel A
ENC3_B	13	In	Incremental Encoder Interface 3 Channel B
ENC3_N	14	In	Incremental Encoder Interface 3 Channel N
			(Connect to +5V if not used)
TDI	2		Connect to Ground
TMS	7		Connect to 5 Volt via Pull-Up Resistor
TRST	16		Connect to 5 Volt via Pull-Up Resistor
TDO	49		To be left open
ТСК	100		Connect to Ground
VCCI	8, 20, 44, 58, 82	In	Positive Power Supply 5 Volt
VCCA	35, 57, 67, 90	In	Positive Power Supply 2.5 Volt
GND	39	In	Unused input: Connect to Ground
CLK	88	In	System Clock 16MHz
EXT_RES	87	In	External Reset Low Active
NC	37, 89	In	Connect to Ground
PRA / IO	92		To be left open
PRB / IO	34		To be left open
Step 1	15	Out	Step/Direction Interface – Step Output Motor 1
Dir 1	18	Out	Step/Direction Interface – Direction Output Motor 1
Step 2	21	Out	Step/Direction Interface – Step Output Motor 2
Dir 2	22	Out	Step/Direction Interface – Direction Output Motor 2
Step 3	24	Out	Step/Direction Interface – Step Output Motor 3
Dir 3	25	Out	Step/Direction Interface – Direction Output Motor 3
SDO_D	26	Out	Step / Direction SPI MISO
SDI_D	27	In	Step / Direction SPI MOSI
SCK_D	28	In	Step / Direction SPI SCK
NSCS_D	29	In	Step / Direction SPI NSCS
REFo	40	Out	Reference switch output 1
REF1	41	Out	Reference switch output 2
REF2	42	Out	Reference switch output 3
STOPRo	43	In	Right Stop Switch Motor 1
STOPR1	45	In	Right Stop Switch Motor 2
STOPR2	46	In	Right Stop Switch Motor 3
STOPLo	47	In	Left Stop Switch Motor 1
STOPL1	48	In	Left Stop Switch Motor 2
STOPL2	50	In	Left Stop Switch Motor 3
COLUMN_PINo	75	Out	Column Drive Pin o
COLUMN_PIN1	74	Out	Column Drive Pin 1
COLUMN_PIN2	73	Out	Column Drive Pin 2
COLUMN_PIN3	72	Out	Column Drive Pin 3
SW_ROW_PINo	65	In	Switch Matrix Pin o
SW_ROW_PIN1	64	In	Switch Matrix Pin 1
SW_ROW_PIN2	63	In	Switch Matrix Pin 2
SW_ROW_PIN ₃	62	In	Switch Matrix Pin 3

SW ROW PIN4	61	In	Switch Matrix Pin 4
SW_ROW_PIN5	60	In	Switch Matrix Pin 5
LED_ROW_PINo	59	Out	LED Matrix Drive Pin o
LED_ROW_PIN1	56	Out	LED Matrix Drive Pin 1
LED_ROW_PIN2	55	Out	LED Matrix Drive Pin 2
LED_ROW_PIN3	54	Out	LED Matrix Drive Pin 3
LED_ROW_PIN4	53	Out	LED Matrix Drive Pin 4
LED_ROW_PIN5	52	Out	LED Matrix Drive Pin 5
SDO	99	Out	SPI MISO
SDI	98	In	SPI MOSI
SCK	97	In	SPI SCK
NSCS	96	In	SPI NSCS
SD0428	95	In	SPI MISO Pin of TMC428
NSCS428	94	In	SPI NSCS Pin of TMC428
NINT	93	Out	Interrupt Output (low active)

Table 1: TMC423 Pinout

Note: Pins which are not marked in Figure 1: Pinout TMC423 on page 5 must be left open.

1.2 Recommended Operating Conditions

Parameter	Value	Unit
Clock Frequency (1)	16	MHz
Temperature	0 + 70	°C
2.5 V Power Supply	2.25 2.75	V _{CCA}
5.0 V Power Supply	4.50 5.50	V _{CCI}

Table 2: Operating Conditions

 slower frequencies are also supported. Please take care about the timing information in this datasheet, since they are based on 16MHz Clock Frequency.

1.3 Electrical Characteristics

Parameter	Min	Max	Unit
Supply Current 2.5V		100	mA
Supply Current 5.0V		10	mA
(Output current = o)			
LED driver current per pin		20	mA
Input voltage level Low		0.8	V
Input voltage level High	2.4		V
Encoder input pulse length	2 t _{CLK}		
Encoder count rate		f _{ськ}	

Table	3:	Operating	Conditions
-------	----	-----------	------------

2 Block Diagram




Figure 2: Block diagram of the TMC423

3 Application Environment

TMC423 as Incremental Encoder Interface




Figure 3: Application Environment

Application Description 3.1

Application with TMC236 Stepper Motor Driver 3.1.1

A complete close-loop motion control system consists of the TMC428 three-axis motion controller, the powerful TMC236 stepper motor driver and the TMC423 Encoder Interface. The system is controlled by an inexpensive microcontroller.

The main advantage of the system is that time critical communication to the TMC236 driver is performed by the TMC428. The main purpose of the inexpensive microcontroller is to parameterize the TMC428 and TMC423 and to send motion parameters like maximum speed or target position to the TMC428. Position validation is done by reading the actual position of the TMC428 and the TMC423.

Application with Step / Direction Power Stage 3.1.2

Another possibility to built a close loop motion control system is to use the TMC423 as encoder interface and also as a step direction converter. Thereto the TMC423 converts the SPI[™] datagrams sent by the TMC428 into parameterizeable step and direction pulses. For parameterizing both the TMC428 and TMC423 have to be connected via SPI[™] interface to an inexpensive microcontroller.

3.2.1 Application with TMC236 Stepper Motor Driver

This example illustrates the encoder connection and the use of reference switches with the TMC423 and additionally the SPI interface connections between TMC423, TMC428 and a microcontroller. The communication to the drivers (e.g. TMC236) is performed via SPI by the TMC428 motion control chip.




Figure 4: Example for Application with TMC236 Stepper Motor Driver

3.2.2 Application with Step / Direction Power Stage

Additionally to the previous example the use of the TMC423 as step/direction converter is shown. The reference switches can be used as above.




Figure 5: Example for Application with Step / Direction Power Stage

4 Dynamic Resolution Adaptation

The dynamic resolution adaptation is needed to link stepper motors and encoders with different resolutions. The characteristics of the connected hardware must provided to the TMC423 by sending the corresponding SPI telegram. (See 5.3.1 Overview on page 13 in this issue). The TMC423 multiplies the encoder counter by a user selectable value in the range 1..1024, and then divides it by 16. When using incremental encoders with N channel it is also possible to select between different behaviors when the N channel is triggered.




Figure 6: TMC423 Application

Table 4 shows a number of prescaler factors for possible combinations of micro step resolution and encoder resolution. Note: The given number of pulses have to be multiplied by four since 4-times encoder signal evaluation is used. (See Figure 10: Encoder Output and Evaluation on page 14).

Microstep			Er	ncoder R	esolution	[Pulses	Rotatio	n]		
S	1024	1000	512	500	256	250	200	125	50	25
12800	3.125	3.2	6.25	6.4	12.5	12.8	16	25.6	64	
6400	1.5625	1.6	3.125	3.2	6.25	6.4	8	12.8	32	64
3200			1.5625	1.6	3.125	3.2	4	6.4	16	32
1600					1.5625	1.6	2	3.2	8	16
800							1	1.6	4	8
400									2	4

Table 4: Prescaler factors for different motors and encoders

5 Serial Peripheral Interface (SPI) with 32-bit Register

5.1 Description and Specification

Four pins named nSCS, SCK, SDI and SDO form the serial peripheral interface from a microcontroller to the TMC423. The communication between the microcontroller and the TMC423 takes place via datagrams with a fixed length of 32 bit. The microcontroller acts always as master and the TMC423 as slave.

The SPI[™] of the TMC423 behaves like a simple 32-bit shift register. Incoming serial data at pin SDI is shifted with the rising edge of the clock signal SCK into the 32-bit register. The content of this register is copied after 32-bits with the rising edge of the selection signal nSCS into a buffer register of 32-bit length. The SPI[™] of the TMC423 sends back data read from registers immediately via the SDO signal. It processes serial data synchronously to the clock signal CLK.

Because of on-the-fly processing of the input data stream, the serial microcontroller interface of the TMC423 requires the serial data clock signal SCK to have a minimum low / high time of three clock cycles. The data signal SDI driven by the microcontroller has to be valid at the rising edge of the serial data clock input SCK. The maximum duration of the serial data clock period is unlimited.

A complete serial datagram frame has a fixed length of 32 bit. While the data transmission from the microcontroller to the TMC423 is idle, the low active serial chip select input nSCS and also the serial data clock signal SCK are set to high. The serial data input SDI of the TMC428 has to be driven by the microcontroller. Like other SPI compatible devices, the SDO signal of the TMC423 is high impedance 'Z' as long as nSCS is high.

The signal nSCS has to be high for at least three clock cycles before starting a datagram transmission. To initiate a transmission, the signal nSCS has to be set to low. Three clock cycles later the serial data clock may go low. The most significant bit (MSB) of a 32 bit wide datagram comes first and the least significant bit (LSB) is transmitted as the last one. A data transmission is finished by setting nSCS high for three or more CLK cycles after the last rising SCK slope. nSCS and SCK change in opposite order from low to high at the end of a transmission as these signals change from high to low at the beginning. The timing of the serial microcontroller interface is outlined in Figure 7: *Timing diagram of the Serial Interface*.




Figure 7: Timing diagram of the Serial Interface

5.2 32-bit SPI Datagram Structure

	Datagram from TMC423 send to μ C																															
3 1	3	3	2 9	2 8	2 7	2 6	2 5	2 4	2 3	2 2	2 1	2 0	1 9	1 8	1 7	1 6	1 5	1 4	1 3	1 2	1 1	1 0	9	8	7	6	5	4	3	2	1	0
	I	N	Г		0	0	0	0		Data																						

Datagram from µC to TMC423														
3 3 2 2 2 2 2 2 2 2 1														
Address ^R _W	Data													

Figure 8: Structure 32-Bit Interface

Interrupt Flags [Bit]	Name	Description
31	INT_ext	external Interrupt, e.g. TMC428
30	INT_enc1	N Signal of Encoder Interface 1 detected
29	INT_enc2	N Signal of Encoder Interface 2 detected
28	INT_enc3	N Signal of Encoder Interface 3 detected

Table 5: Interrupt Flags

5.3 SPI 32-bit Datagram Specification

5.3.1 Overview

Byte #				By	te :	3					E	Зу	te	2							В	yt	:e '	1				Byte 0							
Bit #	31	30	29	28	27	26	25	24	23	23 22 21 20 19 18 17 16 15								14	4 1	3	12	11	10	9	8	7	6	5	4	4	3	2	1	0	
			Ac	ddre	SS			R V																											
Control	0	0	0	0	0	0	0	1		Encoder 1 Presca													>							F	Res	erv	ed		
	0	0	0	0	0	0	1	1				Е	ncc	oder	2	Pres	ca	ler					Polarity	N Hold	Clear	Trigger	ction			F	Res	erv	ed		
	0	0	0	0	0	1	0	1				Е	ncc	oder	3	Pres	ca	er					N Po	Z	2 Z	I Z	Direction			F	Res	erv	ed		
	0	0	0	0	0	1	1	1	Er	ncoc	ler 1	, 2,	3 F	Pres	са	ler -	se	t all	со	mm	nonl	у						Reserved							
Data	0	0	0	0	1 	0	0	 										Encoder 1 Position Register																	
	0	0	0	0	1 1	0	1											Encoder 2 Position Register							ter	-	 								
	0	0	0	0	, 1	1	0											Encoder 3 Position Register							ter										
Step /Dir	0	0	0	0	1	1	1	1		S	Step	Pul	se	Len	gth	1					St	ep	Pu	se	Dela	ıy		Reserved							
INT	0	0	0	1 1 1 1 1		0	0	1 1 1 1 1 1 1	Reg Hold	Reg Hold INT EN Clear Flags													Re	ser	ved										
Matrix	0	0	0	1	0	0	1	0		Switch Row 3							Switch Row 2 Switch R							n Ro	w 1			5	Swit	tch	Row	/ 0			
	0	0	0	1	0	1	0	1		LED Row 3 LE								ED F	Ro	w 2			LED Row					LED Row 0							

Figure 9: Overview TMC423 Registers

6 Incremental Encoder

Incremental Encoders are translating the rotary motion of a shaft into a two-channel digital quadrature output. The light emitted from a LED is focused onto a reflective code wheel. As the shaft moves, the code wheel rotates, reflecting light from an alternating bright and dark pattern.

The TMC423 samples the incoming signals $ENCx_a$ and $ENCx_B$ from the incremental encoder. A internal algorithm block counts the amount of edges generated by the encoder. A prescaler value can be used to adapt the incremental encoder resolution to the stepper motor resolution.

For high resolution the TMC423 evaluates the encoder signals 4-times during each encoder step. This has to kept in mind when choosing the prescaler value.




Figure 10: Encoder Output and Evaluation

Note: It is possible that the encoder signals ENCx_A, ENCx_B and ENCx_N are polluted with crosstalk noise. Crosstalk could influence the internal logic, to overcome this problem internal filters are applied to ensure correct functionality. Furthermore is saves the need for external analog filters. e.g.: Figure 11: Crosstalk on Encoder Wire shows crosstalk from channel A to channel B.




Figure 11: Crosstalk on Encoder Wire

7 Configuration Datagrams

7.1 Encoder Interface Prescaler and Null Event Configuration

The Encoder Interface Initialization datagram configures the parameterizeable encoder prescaler to adapt the TMC423 for different incremental encoders. Furthermore the TMC423 behavior concerning the N channel can be selected.

Example: A 1000 steps per rotation encoder is to connect at a stepper motor with 12800 microsteps per rotation. When the next event at the high active N channel is found, the position register must set to zero. Only Encoder Interface 1 is connected. The following datagram performs this task:

- Bits 31 down to 24 have to be set to $O1_{HEX}$ to select encoder interface 1
- The prescaler value has to set to 12800 / (1000*4) = 3.2. Therefore bits 23 down to 12 must set to 831_{HEX}.
- The N channel is set up correctly when bits 11 down to 0 are set to Ao_{HEX} .

Bit	Encoder Interface Initialization
3128	"oooo" Register Address
2725	Interface Selection
	000 = Interface 1
	001 = Interface 2
	010 = Interface 3
	011 = Interface 1, 2 and 3
24	'1'
2312	External Encoder Resolution and Corresponding Prescaler Factor
	Bits 15 12: Fractional part of Factor. Unit: 1/16 (when bit 23 = 0) resp. 1/5 (bit 23 = 1)
	Bits 22 16: Integer part of Factor
	Bit 23: Switches Fractional part between 1/5 resolution or 1/16 resolution
	Default:
	(010), (prescaler 1) (default value after power on)
	Example settings:
	Encoder: 1024 lines (4096 steps per rotation)
	$(032)_h$ for 12800 micro steps per rotation (prescaler 3.125) $(019)_h$ for 6400 micro steps (prescaler 1.5625)
	Encoder: 1000 lines
	(831) h for 12800 micro steps (prescaler 3.2)
	(813) _h for 6400 micro steps (prescaler 1.6)
	Encoder: 512 lines
	(064) _h for 12800 micro steps (prescaler 6.25)
	$(032)_h$ for 6400 micro steps (prescaler 3.125) $(019)_h$ for 3200 micro steps (prescaler 1.5625)
	Encoder: 500 lines
	(862) _h for 12800 micro steps (prescaler 6.4)
	(831) _h for 6400 micro steps (prescaler 3.2) (813) _h for 3200 micro steps (prescaler 1.6)
	Encoder: 256 lines
	$(oC8)_h$ for 12800 micro steps (prescaler 12.5) $(o64)_h$ for 6400 micro steps (prescaler 6.25)
	$(032)_h$ for 3200 micro steps (prescaler 3.125)
	(019) _h for 1600 micro steps (prescaler 1.5625)
	Encoder: 250 lines
	(8C4) _h for 12800 micro steps (prescaler 12.8)
	(862) _h for 6400 micro steps (prescaler 6.4)
	(831) _h for 3200 micro steps (prescaler 3.2) (813) _h for 1600 micro steps (prescaler 1.6)
	Encoder: 200 lines
	(100) _h for 12800 micro steps (prescaler 16)
	(080) _h for 6400 micro steps (prescaler 8)
	(040) _h for 3200 micro steps (prescaler 4) (020) _h for 1600 micro steps (prescaler 2)
L	

i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
 (993), for 12800 micro steps (prescaler 22.6) (862b, for 2800 micro steps (prescaler 12.8) (862b, for 3200 micro steps (prescaler 3.2) (833), for 1600 micro steps (prescaler 3.2) (833), for 1600 micro steps (prescaler 3.2) (833), for 12800 micro steps (prescaler 3.2) (800), for 12800 micro steps (prescaler 4.4) (200), for 12800 micro steps (prescaler 3.2) (100), for 12800 micro steps (prescaler 3.2) (100), for 12800 micro steps (prescaler 3.2) (100), for 1600 micro steps (prescaler 4.4) (100), for 1600 micro steps (prescaler 4.4) (100), for 1600 micro steps (prescaler 2.1) (11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, <i>i.e.</i> to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		(010) _h for 800 micro steps (prescaler 1)
 (862), for 6400 micro steps (prescaler 3.2) (862), for 3200 micro steps (prescaler 3.2) (833), for 800 micro steps (prescaler 3.2) (833), for 800 micro steps (prescaler 3.2) (833), for 800 micro steps (prescaler 4.6) (200), for 12800 micro steps (prescaler 3.2) (100), for 3200 micro steps (prescaler 3.2) (101), for 200 steps per rotation (prescaler 1.1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event lost until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		Encoder: 125 lines
 (662), for 3200 micro steps (prescaler 3.2) (831), for 1600 micro steps (prescaler 3.2) (833), for 12800 micro steps (prescaler 1.6) Encoder: so lines (200 steps per rotation) (400), for 12800 micro steps (prescaler 3.2) (1200), for 12800 micro steps (prescaler 3.2) (1200), for 3200 micro steps (prescaler 3.2) (1200), for 1600 micro steps (prescaler 3.2) (1200), for 3200 micro steps (prescaler 1.2) (1200), for 400 micro steps (prescaler 1.2) (1200), for 200 steps per rotation (prescaler 1.2) (12		(993) _h for 12800 micro steps (prescaler 25.6)
 (83), for 1600 micro steps (prescaler 3.2) (83), for 800 micro steps (prescaler 1.6) Encoder: 50 lines (200 steps per rotation) (400), for 12800 micro steps (prescaler 32) (100), for 1200 micro steps (prescaler 32) (100), for 3200 micro steps (prescaler 16) (080), for 1600 micro steps (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		(8C4) _h for 6400 micro steps (prescaler 12.8)
 (813)^h for 800 micro steps (prescaler 1.6) Encoder: so lines (200 steps per rotation) (400)^h for 12800 micro steps (prescaler 64) (200)^h for 3200 micro steps (prescaler 76) (000)^h for 300 micro steps (prescaler 16) (000)^h for 300 micro steps (prescaler 2) (000)^h for 200 micro steps (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 Encoder: 50 lines (200 steps per rotation) (400), for 12800 micro steps (prescaler 64) (200), for 5200 micro steps (prescaler 32) (100), for 3200 micro steps (prescaler 32) (100), for 300 micro steps (prescaler 4) (020), for 300 micro steps (prescaler 2) (030), for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active 9 Clear on N Event for Selected Interface 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 (400), for 12800 micro steps (prescaler 32) (100), for 12800 micro steps (prescaler 32) (100), for 3200 micro steps (prescaler 32) (100), for 300 micro steps (prescaler 4) (020), for 400 micro steps (prescaler 2) (010), for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		(013) ^h for 800 millio steps (prescale) 1.0
 (200), for 6400 micro steps (prescaler 32) (200), for 3200 micro steps (prescaler 16) (080), for 1600 micro steps (prescaler 8) (040), for 800 micro steps (prescaler 2) (020), for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 (100)^h for 3200 micro steps (prescaler 16) (080)_h for 3000 micro steps (prescaler 4) (040)_h for 800 micro steps (prescaler 2) (010)_h for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface o = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface o = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface o = no clear (default) 1 = active when the N channel becomes active. 8 N Trigger Selection o = only at next N signal o = only at next N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, <i>i.e.</i> to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 (080)^h/_h for 1600 micro steps (prescaler 8) (040)^h, for 800 micro steps (prescaler 2) (020)^h, for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, <i>i.e.</i> to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 (a40)^h for 800 micro steps (prescaler 4) (a20)_h for 200 steps per rotation (prescaler 2) (a10)^h for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface a = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface o = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface o = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection o = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
(020), for 400 micro steps (prescaler 2) (010), for 200 steps per rotation (prescaler 1) 11 N Polarity for Selected Interface 0 = active low (default) 1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
 (010)_h for 200 steps per rotation (prescaler 1) N Polarity for Selected Interface active low (default) active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. Hold on N for Selected Interface o = no hold (default) active: Encoder counter freezes during o channel event. Clear on N Event for Selected Interface o = no clear (default) active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. N Trigger Selection o = only at next N signal (default) always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, <i>i.e.</i> to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 o = active low (default) active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. Hold on N for Selected Interface no hold (default) active: Encoder counter freezes during o channel event. Clear on N Event for Selected Interface no clear (default) active when switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. N Trigger Selection o = only at next N signal (default) always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		(010) _h for 200 steps per rotation (prescaler 1)
1 = active high When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.	11	,
When changing the polarity, please be aware that a single clear on N Event might be triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
triggered, and thus should not be initiated in the same write access. 10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during o channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
10 Hold on N for Selected Interface 0 = no hold (default) 1 = active: Encoder counter freezes during 0 channel event. 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
 0 = no hold (default) active: Encoder counter freezes during o channel event. Clear on N Event for Selected Interface no clear (default) active when switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. N Trigger Selection o = only at next N signal (default) always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		triggered, and thus should not be initiated in the same write access.
 1 = active: Encoder counter freezes during o channel event. Clear on N Event for Selected Interface o = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. N Trigger Selection o = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 	10	Hold on N for Selected Interface
 9 Clear on N Event for Selected Interface 0 = no clear (default) 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		o = no hold (default)
 0 = no clear (default) active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection o = only at next N signal (default) always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 		
 1 = active When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register. 	9	
When switched to active, then it depends on bit 8, if a clear event is issued only once, or always when the N channel becomes active. 8 N Trigger Selection 0 = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
always when the N channel becomes active. N Trigger Selection o = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		
8 N Trigger Selection o = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		When switched to active, then it depends on bit 8, if a clear event is issued only once, or
o = only at next N signal (default) 1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		always when the N channel becomes active.
1 = always at N signal The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.	8	
The clear event last until the N signal goes inactive again. If earlier termination is desired, i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		o = only at next N signal (default)
i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to changing the position register.		1 = always at N signal
changing the position register.		The clear event last until the N signal goes inactive again. If earlier termination is desired,
changing the position register.		i.e. to preset the encoder counter to a different value, disable "Clear on N" prior to
	7	add or sub register for each step (CW = looking onto the axis)
o= add for CW, sub for CCW (default)		
1= add for CCW, sub for CW		1= add for CCW, sub for CW
6O Reserved	60	Reserved

Table 6: SPI Datagram Prescaler

7.2 Encoder Interface Hold Register Operation

To read the actual contents of the position register or to preset the position register the following command is to be used:

Bit	Encoder Interface Control (Read/Preload Encoder Hold Register)				
3128	"oooo" Register Address				
2725	Select Encoder Hold Register				
	100 = Hold register in encoder interface 1				
	101 = Hold register in encoder interface 2				
	110 = Hold register in encoder interface 3				
24	Read or Preload Selection				
	o = Read encoder hold register				
	1 = Preload encoder hold register				
230	Encoder Hold Register Data				

Table 7: SPI Datagram Hold Register

7.3 Timer Logic Step Pulse Length and Delay

To parameterize the step length and delay the next datagram is to be used:

Bit	Write Step Pulse Length / Delay
3125	"0000111" Register Address
24	'1'
2316	Step Pulse Length (default value = 48(10) after PON)
156	Step Pulse Delay after Direction Change (default value = $160_{(10)}$ after PON)
50	Reserved

Table 8: SPI Datagram Step-/Dir logic

7.4 Control Register and Interrupt Control

This datagram configures the interrupt control of the TMC423. When enabled, the N channel pulse of all encoders is fed to the NINT pin.

Bit	Control Register
3125	"0001000" Register Address
24	'1'
23	Set Common Hold for Encoder Hold Registers
	o = no hold (default)
	1 = freeze encoder hold registers
22	Encoder Interrupt Enable, if Null signal
	o = interrupt disable (default)
	1 = interrupt enable
21	Clear Interrupt Flags
	o = no clear (default)
	1= clear flags
200	Reserved

Table 9: SPI Datagram Control Register

7.5 Switch Matrix Read

Bit	Control Register
3125	"0001001" Register Address
24	'o'
2318	Switch Matrix Register Row 3
1712	Switch Matrix Register Row 2
116	Switch Matrix Register Row 1
50	Switch Matrix Register Row o

Table 10: Switch Matrix Read

7.6 LED Matrix Write

Bit	Control Register
3125	"0001010" Register Address
24	'1'
2318	LED Matrix Register Row 3
1712	LED Matrix Register Row 2
116	LED Matrix Register Row 1
50	LED Matrix Register Row o

Table 11: LED Matrix Write

8 SPI-Protocol for Interface with 6-bit Register

The 6-bit SPI Interface is used to receive step / direction information from the TMC428. The TMC423 processes the data and issues the corresponding step / direction signals via the step / direction pins. Bito (Pulse 1) have to be sent first to the TMC423.

Bit	Step / Direction Converter					
0	Pulse 1					
1	Direction 1					
2	Pulse 2					
3	Direction 2					
4	Pulse 3					
5	Direction 3					

Table 12: SPI Datagram Step / Direction Converter

The order of the control signals serially sent from the TMC428 has to be defined. This can be done by writing so called primary signal codes into the stepper motor driver datagram configuration area of the on-chip configuration RAM of the TMC428. This signals codes are \$13 (step first) and \$12 (direction). To switch to the next motor the next motor bit (NxM) has to be set.

Position within	Driver/motor	NxM bit	TMC428 signal	RAM data	TMC428
datagram			code		mnemonic of
					primary signal
0	1	0	\$13	\$13	Step
1	T	1	\$12	\$32	Direction
2	2	0	\$13	\$13	Step
3	2	1	\$12	\$32	Direction
4	n	0	\$13	\$13	Step
5	3	1	\$12	\$32	Direction

Table 13: Datagram example and RAM contents for three step-direction drivers

8.1 Step and Direction Pulse conversion

Step pulses can be modified in their pulse width and delayed after an direction change was done. The corresponding datagram (See 7.3) on page 17) is used to parameterize the Step / Dir interface.




Figure 12: Step Direction conversion

9 LED and Switch Matrix

The TMC423 can be used to drive a LED matrix or to get information from a switch matrix, whether the switches are on or off. LEDs or switches are only active when the corresponding column is selected by setting it to zero. The switch frequency of the column pins is fixed to 500 Hz at a clock frequency of 16MHz. The LEDs are driven with a maximum current of 20mA.

The following Table 14: TMC423 LED Matrix Pins shows how the LED Matrix Write register is mapped to the corresponding TMC423 pins to drive the LEDs.

TMC423 Pin: COLUMN_PIN [3:0]				TMC4	23 Pin: LED	_ROW_PII	N [5:0]		
Bit 3	Bit 2	Bit 1	Bit o	LED_Matrix_Write [23:0]					
0	1	1	1	23	22	21	20	19	18
1	0	1	1	17	16	15	14	13	12
1	1	0	1	11	10	9	8	7	6
1	1	1	0	5	4	3	2	1	0

Table 14: TMC423 LED Matrix Pins

For correct external connection of the matrix please refer to the following Figure 13: Connection to the matrix. If distortions causes by long PCB traces are to expect, then filter capacitors C_{filter} of 100pF have to be added.





Figure 13: Connection to the matrix

10 Package dimensions



R 0.08 Min.

Figure 16: 100-Pin TQFP Side View Detail A

JEDEC Equivalent	TQFP100 MS-026 VAR BED				
Dimension	Min	Nom	Max		
А			1.60		
Aı	0.05		0.15		
Az	1.35	1.40	1.45		
b	0.17	0.22	0.27		
С	0.09	0.20			
D/E					
D1/E1	14.00 BSC				
е	0.50 BSC				
L	0.45 0.60 0.75				
ccc	0.08				
Theta	0 3.50 deg 7 deg				

Table 15: TQFP Dimensions

Notes :

- all dimensions are in millimeters

- BSC Basic Spacing between Centers

Life support policy

TRINAMIC Motion Control GmbH & Co. KG does not authorize or warrant any of its products for use in life support systems, without the specific written consent of TRINAMIC Motion Control GmbH & Co. KG. Life support systems are equipment intended to support or sustain life, and whose failure to perform, when properly used in accordance with instructions provided, can be reasonably expected to result in personal injury or death.

© 2004 TRINAMIC Motion Control GmbH & Co. KG

Information given in this data sheet is believed to be accurate and reliable. However no responsibility is assumed for the consequences of its use nor for any infringement of patents or other rights of third parties, which may result form its use.

Specifications subject to change without notice.